


# Partition Extender / PEXXXXX-T Adhesive Unit


## Installation Instructions

**Step 1:** Remove and unpack the Acrylic Panel, Brackets, and Hardware.




Note: Custom sizes with panel width larger than 72" will receive 4 sets of brackets. Standard sizes with panel width larger than 48" will receive 3 sets of brackets, all smaller sizes will receive 2 sets.

**Step 2:** Assemble all Standoffs and Feet together using the 5/16-18 x 12" flat head screw.




**Step 3:** Slide the Acrylic Panel into the Standoffs. Secure the Acrylic Panel by tightening the set screws in the Standoff with the provided Allen Wrench.



**Step 4:** Clean the mounting surface with isopropyl alcohol or similar to remove all dust, dirt, or debris

**Step 5:** Remove the liner on the tape (located on the bottom of the Foot) and secure to the top of the desk/table using firm pressure.



**Step 6:** Recycle all packaging in accordance to local regulations.